

商品名	EXCELバイオBB弾
重量	0.2g
購入日	2013年11月27日
検証方法	ランダムピッキングし重量を測定、その後回転させながらランダムに4カ所測定する。



試験体No.	重量 (g)	サイズ測定(mm)				平均(mm)
		1回目	2回目	3回目	4回目	
1	0.20	5.93	5.88	5.91	5.92	5.91
2	0.19	5.92	5.93	5.89	5.94	5.92
3	0.20	5.86	5.87	5.90	5.88	5.88
4	0.20	5.92	5.88	5.91	5.92	5.91
5	0.20	5.94	5.93	5.88	5.94	5.92
6	0.18	5.94	5.90	5.93	5.95	5.93
7	0.20	5.91	5.92	5.89	5.91	5.91
8	0.20	5.94	5.87	5.92	5.94	5.92
9	0.19	5.89	5.91	5.92	5.88	5.90
10	0.19	5.89	5.87	5.90	5.86	5.88
11	0.20	5.93	5.90	5.86	5.89	5.90
12	0.19	5.88	5.92	5.92	5.90	5.91
13	0.19	5.90	5.91	5.92	5.92	5.91
14	0.20	5.93	5.89	5.90	5.92	5.91
15	0.20	5.94	5.88	5.92	5.94	5.92
16	0.20	5.92	5.93	5.91	5.89	5.91
17	0.19	5.94	5.88	5.88	5.91	5.90
18	0.20	5.93	5.91	5.89	5.93	5.92
19	0.19	5.88	5.91	5.93	5.92	5.91
20	0.19	5.92	5.93	5.95	5.92	5.93
21	0.20	5.89	5.92	5.94	5.92	5.92
22	0.20	5.91	5.90	5.89	5.91	5.90
23	0.20	5.89	5.90	5.91	5.91	5.90
24	0.20	5.88	5.93	5.95	5.89	5.91
25	0.19	5.94	5.93	5.88	5.93	5.92
26	0.20	5.88	5.85	5.85	5.86	5.86
27	0.20	5.91	5.88	5.87	5.87	5.88
28	0.20	5.89	5.89	5.90	5.88	5.89
29	0.20	5.92	5.89	5.88	5.87	5.89
30	0.20	5.89	5.89	5.90	5.91	5.90
31	0.19	5.89	5.89	5.92	5.93	5.91
32	0.19	5.89	5.93	5.91	5.88	5.90
33	0.20	5.86	5.90	5.94	5.95	5.91
34	0.20	5.91	5.87	5.88	5.89	5.89
35	0.19	5.93	5.93	5.88	5.92	5.92
36	0.20	5.89	5.90	5.90	5.88	5.89
37	0.21	5.91	5.90	5.89	5.90	5.90
38	0.20	5.88	5.88	5.87	5.87	5.88
39	0.19	5.86	5.92	5.92	5.91	5.90
40	0.21	5.90	5.89	5.90	5.90	5.90
41	0.20	5.93	5.91	5.87	5.91	5.91
42	0.20	5.90	5.88	5.91	5.90	5.90
43	0.21	5.87	5.92	5.92	5.91	5.91
44	0.20	5.91	5.91	5.88	5.86	5.89
45	0.19	5.88	5.89	5.89	5.89	5.89
46	0.20	5.84	5.88	5.83	5.86	5.85
47	0.20	5.92	5.85	5.90	5.94	5.90
48	0.19	5.91	5.89	5.87	5.85	5.88
49	0.20	5.91	5.89	5.90	5.91	5.90
50	0.20	5.87	5.90	5.92	5.90	5.90
平均	0.197					5.901

色分け表

重量	サイズ
0.18g(-0.02g)以下	5.95mm
0.19g(-0.01g)	5.94mm
0.2g	5.93mm
0.21g(+0.01g)	5.92mm以下
0.22g(+0.02g)以上	

LayLax 